

# MATERIALS CENTRAL TECHNICAL LIBRARY OFFICIAL FILE COPY

PCTR 4577 5 August 1963

AD-416224

PROCESS CONTROL - EFFECT OF ACID CLEANING
ON THE MECHANICAL PROPERTIES OF 17-4 PH STEEL
IN VARIOUS HEAT TREATED CONDITIONS

Published and distributed under Contract No. AF33(657)-11214, Air Force Materials Laboratory, Aeronautical Systems Division, Air Force Systems Command, Wright-Patterson AF Base, Ohio,

GENERAL DYNAMICS FORT WORTH



UMBER	4577

DATE Feb. 1961

MODEL\_\_\_\_

TITLE

PROCESS CONTROL - EFFECT OF ACID CLEANING ON THE MECHANICAL PROPERTIES OF 17-4 PH STEEL IN VARIOUS HEAT TREATED CONDITIONS

The Tests described in this report were conducted between 7-25-60 and 11-29-60

## CONVAIR

A DIVISION OF GENERAL DYNAMICS CORPORATION
(FORT WORTH)

PREPARED B	ВY	W	M	A.	To	ken
				Token		
		Sr.	Me	tallur	gist	

CHECKED BY

SECTION Metallurgical

APPROVED BY Planista

el



PAGE 1 NUMBER 4577 DATE Feb. 1961

PROCESS CONTROL-EFFECT OF ACID CLEANING ON THE MECHANICAL PROPERTIES
OF 17-4 PH STEEL IN VARIOUS HEAT TREATED CONDITIONS

#### PURPOSE:

To determine if the cleaning procedure specified in Process Standard 61.32B\* embrittles aged 17-4 PH steel parts.

#### SUMMARY:

Cleaning 17-4 steel parts as specified in Process Standard 61.32B will not produce embrittlement in 17-4 PH wrought forms at nominal strength levels.

Cleaning 17-4 PH castings as specified in Process Standard 61.32B could not be evaluated because of the inherent structural characteristic of low ductibility at 180 K.S.I. minimum strength.

Because of the difficulty in controlling aggregate immersion time, 17-4 PH steel parts, castings and wrought, should not be acid pickled. Acid pickling will not embrittle 17-4 PH steel parts, but susceptibility to failure due to intergranular attack will increase proportionally to increase in immersion time.

\*General Dynamics/Fort Worth Process Standard See Page 3 for procedure



PAGE 2 NUMBER 4577 DATE Feb. 1961

TITLE: PROCESS CONTROL-EFFECT OF ACID CLEANING ON THE MECHANICAL PROPERTIES OF 17-4 PH STEEL IN VARIOUS HEAT TREATED CONDITIONS

#### OBJECT:

To determine if acid cleaning as specified in Process Standard 61.32, and other solutions, can be used to clean 17-4 PH steel parts.

#### SPECIMENS:

Compression Ring-Stress Bar specimens Notched and Un-notched tensile specimens

Compression ring-stress bar specimens were produced from 17-4 PH castings and 17-4 PH bar material. The notched and un-notched tensile specimens were produced from 17-4 PH bar material.

#### TESTING APPARATUS:

Baldwin Southwark 60,000 # tensile machine, Industrial Filter and Pump Mfg. Co. - Salt Spray Cabinet

#### PROCEDURE:

Notched, un-notched tensile and compression ring-stress bar specimens were aged to both 900° and 1100°F and processed as follows:

#### A.-17-4 PH Casting - Compression ring-stress bar specimens

- 1. Control as received = 900°F and 1100°F\* age.
- \*\* 2. Annealed \* Pickle solution \* 900°F age.
- \*\* 3. Annealed + Pickle solution + 1100°F age.
  - 4. As received (900°F age) + Pickle solution.
  - 5. As received (1100°F age) → Pickle solution.
  - 6. Annualed P.S. 61.32B cleaning 900°F age.
  - 7. Annealed + P.S. 61.32B cleaning + 1100°F age.
  - 8. As received (900°F age) P.S. 61.32B cleaning.
  - 9. As received (1100°F age) + P.S. 61.32B cleaning.
  - 10. Annealed + Armco Pickle + 900°F age.
  - 11. Annealed Araco Pickle 1100°F age.
  - 12. As received (900°F age) Armoo Pickle.
  - 13. As received (1100°F age) + Armeo Pickle.
  - .010" removed from O.D.
- .010" removed from 0.D. prior to anneal

# B.-17-4 PH Bar material - Compression ring - stress bar and notched and un-notched tensile specimens.

- 1. Control 900°F and 1100°F age.
- 2. Pickle solution and 900°F age.
- 3. Pickle solution + 1100°F age.
- 4. 900°P age . Pickle solution.
- 5. 1100°F age \* Pickle solution.



PAGE NUMBER DATE Feb. 1961

- 6. P.S. 61.32B cleaning 900°F age.
- 7. P.S. 61.32B cleaning 1100°F age. 8. 900°F age P.S. 61.32B cleaning
- 9. 1100°F age + P.S. 61.32B cleaning
- 10. Armco pickle + 900°F age.
- 11. Armco pickle + 1100°F age.
- 12. 900°F age + Armco pickle.
- 13. 1100°F age + Armco pickle.

#### C.-Compression ring - stress bar specimens were also given the following evaluation:

- 1. Control 900°F + 1100°F age + salt spray for 6 days.
- 2. 900°F age + Pickle \* solution + salt spray for 6 days.
- 3. 1100°F age + Pickle \* solution + salt spray for 6 days.
- 4. 900°F age + P.S. 61.32B \* cleaning + salt spray for 6 days.
- 5. 1100°F age + P.S. 61.32B \* cleaning + salt spray for 6 days.
  6. 900°F age + Armco \* pickle + Salt spray for 6 days.
- 7. 1100°F age + Armco \* pickle + salt spray for 6 days.
  - The compression ring stress bar specimens were given 3 immersion time (maximum) cycles prior to salt spray evaulation.

The acid solutions used are as follows:

#### 1. P.S. 61.32B cleaning

- a. Vapor Degrease
- b. Clean Nitric acid Water - 17/20% - 80/83% Soduim Dichromate - 3/5 oz/gal.
- c. Immersion for 30 mins. at 143°F.
- d. Rinse

#### 2. Pickle Solution

- a. Vapor Degrease
- b. Pickle Nitric acid Nitric acid - 7/17 - 7/17 - 6/9 oz/gal. Water
- c. Immersion for 15 mins. at 135°F.
- d. Rinse

#### 3. Armco Pickle Solution

- a. Vapor Degrease
- b. Pickle Sulfuric acid 15% Water - remainder
- c. Immersion for 30 mins. at 190°F
- d. Hot water rinse
- e. Pickle Nitric acid Hydrefluoric acid - 25



PAGE 4 NUMBER 4577 DATE Feb. 1961

- f. Immersion for 3 mins. at 140°F
- g. Hot water, high pressure water or brush scrub.

Compression ring-stress bar specimens of Tests A and B stressed after processing.

Compression ring-stress bar specimens of Test C stressed before processing and salt spray evaluation.

Results: Results are listed in Tables I, II, III, IV and V.



PAGE 5 NUMBER 4577 DATE Feb. 1961

#### TABLE I

#### 17-4 PH Casting - H900 Condition-Compression Ring-Stress Bar-Control

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	71.5 - 72.0	540	.210
2.	71.5 - 72.0	605	.310
3.	71.5 - 72.0	<b>7</b> 50	<b>.</b> 500*
4.	71.5	470	.130
5.	71.5 - 72.0	660	<b>.</b> 390
6.	71.5 - 72.0	575	.240
7.	71.5 - 72.0	525	.170
8.	71.5 - 72.0	550	.210
9.	71.5 - 72.0	430	.110
10.	71.5 - 72.0	510	.160

<sup>\*</sup> No failure. Where stress bar was not used, .500" deflection chosen, arbitrarily, as end point. At .500" deflection, compression ring 0.D. parallel.

17-4 PH Casting-H1100 Condition-Compression Ring-Stress Bar-Control

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	62.0 - 62.5	470	.500
2.	63.5 - 64.0	390	.500
3•	63.5 - 64.0	430	.500
4.	66.0 - 67.0	540	.500
5.	64.5 - 65.5	450	.500
6.	67.0 - 67.5	535	.500
7.	67.0 - 67.5	420	.200 *
8.	62.5 - 63.0	385	.500 -
9.	63.5 - 64.5	380	.500 -
10.	66.0 - 67.5	425	.500 -

- \* Failure
- .010" removed from 0.L.



PAGE 6 NUMBER 4577 DATE Feb. 1961

#### TABLE II

#### 17-4PH Bar Material-H900 Condition-Compression Ring-Stress Bar-Control

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	72.0	773	.500
	72.0	786	.500

### 17-4 PH Bar Material-H 1100 Condition-Compression Ring-Stress Bar-Control

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	66.0 - 66.5	570	•500
2.	66.0	590	.500

### 17-4 PH Bar Material-H900 Condition-Compression Ring-Stress Bar-Control\*

Specimen #	Lbs. Deflection	Inches Deflection
1.	565	.200
2.	<b>5</b> 55	.200

#### 17-4 PH Bar Material-H1100 Condition-Compression Ring-Stress Bar-Control\*

Specimen #	Lbs. Deflection	Inches Deflection
1.	445	.200
2.	465	.200

\* These compression rings were stressed to the inches deflection as noted, stress bar inserted and subjected to talt spray for 6 days.



PAGE 7 NUMBER 4577 DATE Feb. 1961

#### TABLE III

### A. - 17-4 PH Casting-Compression Ring-Stress Bar

### \* Annealed + Pickle solution + 900°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	380	.085
2.	505	•500
3.	325	.014
4.	435	.037

### \* Annealed + Pickle solution + 1100°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	330	.023
2.	530	.500
3.	380	.500
4.	395	.500

\* .010" removed from 0.D. prior to anneal

# As received (900°F age) + Pickle solution

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	71.5 - 72.0	590	.500
2.	71.5 - 72.0	370	.190
3.	71.5 - 72.0	450	.390

### As received (1100°F age) + Pickle solution

Specimen #	Rockwell A Hardners	Lbs. Deflection	Inches Deflection
1.	62.0 - 62.5	280	.500
2.	66.5 - 67.0	525	.500
3.	66.5 - 67.0	395	.500

## Annealed + P.S. 61.32B cleaning • 900°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	480	.120
2.	720	.500
3.	715	.500
li.	525	.175



PAGE 8 NUMBER 4577 DATE Feb. 1961

### Annealed \* P.S. 61.32B cleaning \* 1100°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	470	.400
2.	480	.430
3.	470	.500
4.	470	.500

### As received (900°F age) + P.S. 61.32B cleaning

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	71.5 - 72.0	465	.100
2.	71.5	680	.450
3.	71.5 - 72.0	565	.270

# As received (1100°F age) + P.S. 61.32B cleaning

Specimen #	Rockwell A Hardness	Lbs. Deflection	Inches Deflection
1.	63.5	380	.500
2.	66.5	420	.360
*3.	63.5 - 64.0	385	.500

<sup>\* .010&</sup>quot; removed from 0.D.

# Annealed + Armco Pickle + 900°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	670	.500
2.	680	.500
3.	645	.500
<b>4.</b>	685	.500

## Annealed • Armco Pickle • 1100°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	480	.500
2.	515	.500
3.	500	.500
Ĺ.	500	.500

### As received (900°F age) . Armco Pickle

Specimen 🕏	Ibs. Deflection	Inches Deflection
1.	470	.450
2.	505	.470
3.	330	.100



PAGE 9 NUMBER 4577 DATE Feb. 1961

As received (1100°F age) - Armco Pickle

Specimen #	Lbs. Deflection	Inches Deflection
1.	180	•500
2.	375	•500
3.	215	•500



PAGE 10 NUMBER 4577 DATE Feb. 1961

TABLE IV

### B. - 17-4 PH Bar stock-Compression Ring-Stress Bar

## Pickle solution + 900°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	640	.500
2.	780	.500
3.	690	.500

### Pickle solution - 1100°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	625	.500
2.	620	.500
3.	580	.500

## 900°F age → Pickle solution

Specimen #	Lbs. Deflection	Inches Deflection
1.	725	.500
2.	680	.500
3.	675	.500

### 1100°F age + Pickle solution

Specimen #	Lbs. Deflection	Inches Deflection
1.	450	.500
2.	515	.500
3.	480	.500

### P.S. 61.32B cleaning • 900°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	830	.500
2.	795	.500
3.	820	.500

## P.S. 61.32B cleaning • 1100°F age

Specimen \$	Lbs. Deflection	Inches Deflection
1.	610	.500
2.	555	.500
₹.	600	.500

# 900°F age . P.S. 61.32B cleaning

Specimen #	Lbs. Deflection	Inches Deflection
1.	795	.500
2.	790	.500
3.	810	.500



PAGE 11 NUMBER 4577 DATE Feb. 1%1

1100°F age + P.S. 61.32B cleaning

Specimen #	Lbs. Deflection	Inches Deflection
1.	550	.500
2.	620	.500
3.	620	.500

Armco pickle + 900° F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	785	.500
2.	700	.500
3.	720	.500

Armco pickle + 1100°F age

Specimen #	Lbs. Deflection	Inches Deflection
1.	530	•500
2.	555	.500
3.	555	.500

900°F Age + Armco Pickle

Specimen #	Lbs. Deflection	Inches Deflection
1.	510	.500
2.	505	.500
3.	500	.500

1100°F age + Armco Pickle

Specimen #	Lbs. Deflection	Inches Deflection
1.	365	.500
2.	410	.500
3.	360	.500

B. - 17-4 PH Bar stock Mechanical Properties

Notch - Un-notch

900°F age - Controls

Specimen #	.2% Y.S.(K.S.I.)	T.S.(K.S.I.)	Elongation (% in 2")	R. of A. (%)
Un-notched	181.9	197.0	15.4	52.3
notched		289.0		

Notched-Un-notched ratio - 1.47-1



PAGE 12 NUMBER 4577 DATE Feb. 1961

1100°F age - Controls

Specimen # .2% Y.S.(F.S.K.) T.S.(K.S.K.) Elongation (% in 2") R. of A. (%)

Un-notched notched

150.8

155.8

17.9

63.8

Notched-Un-notched ratio - 1.52 - 1

Pickle solution + 900°F age

Specimen # .2% Y.S.(K.S.K.) T.S.(K.S.K.) Elongation (% in 2") R. of A. (%)

Un-notched notched

186.9

198.0 289.6 15.4

53.1

Notched-Un-notched ratio - 1.46 - 1

Pickle solution • 1100°F age

Speci 1 2 .2% Y.S.(K.S.K.) T.S.(K.S.I.) Elongation (% in 2") R. of A. (%)

Un-notched notched

145.8

151.0 235.1 17.9

63.9

Notched-Un-notched ratio - 1.56 - 1

900°F age + Pickle solution

Specimen # .2% Y.S.(K.S.I.) T.S.(K,S.I.) Elongation (% in 2") R. of A. (%)

Un-notched notched

184.0

195.3 280.1 15.4

51.8

Notched-Un-notched ratio - 1.43 - 1

1100°F age - Pickle solution

Specimen # .2% Y.S.(K.S.I.) T.S.(K.S.I.) Elongation (% of 2") R of A. (%)

Un-notched notched

147.6

148.6 229.1 16.1

62.3

Notched-Un-notched ratio - 1.54-1

P.S. 61.32B cleaning • 900°F age

Specimen # .2% Y.S.(K.S.I.) T.S.(K.S.I.) Elongation (% in 2") R. of A. (%)

Un-notched notched

185.8

197.8 274.8 15.4

52.5

Notched-Un-notched ratio - 1.39 - 1



PAGE 13 NUMBER 4577 DATE Feb. 1961

P.S. 61.32B cleaning • 1100°F age

Specimen # .2% Y.S.(K.S.I.) T.S.(K.S.I.) Elongation (% in 2") R. of A. (%)

Un-notched 142.4 150.7 18.0 63.0

notched --- 230.1 --- --
Notched-Un-notched ratio - 1.53 - 1

900°F age + P.S. 61.32B cleaning

 Specimen # .2% Y.S.(K.S.I.)
 T.S.(K.S.I.)
 Elongation (% in 2")
 R. of A. (%)

 Un-notched notched -- 182.8
 197.0
 15.4
 50.6

 notched -- 283.0
 -- -- 

Notched-Un-notched ratio - 1.47 - 1

1100°F age + P.S. 61.32B cleaning

 Specimen # .2% Y.S.(K.S.I.) T.S.(K.S.I.) Elengation (% in 2") R. of A. (%)

 Un-notched notched notched --- 239.0
 151.8 239.0
 17.9 62.5 --- --- -- 

Notched-Un-notched ratio - 1.57 - 1

Armco pickle • 900°F age

 Specimen #
 .2% Y.S.(K.S.I.)
 T.S.(K.S.I.)
 Elongation (% in 2")
 R. of A. (%)

 Un-notched notched -- 188.9
 195.0
 14.3
 49.0

 notched -- 289.0
 -- -- 

Notched-Un-notched ratio - 1.48 - 1

Armco pickle • 1100°F age

Specimen # .2% Y.S. (K.S.I.) T.S.(K.S.I.) Elongation (% in 2") R. of A. (%)
Un-notched 141.4 145.7 14.3 49.0
notched --- 221.4 ---

Notched-Un-notched ratio - 1.52 - 1

900°F age + Armoo Pickle

 Specimen # .2% Y.S.(K.S.I.)
 T.S.(K.S.I.)
 Elongation (\$ in 2")
 R. of A. (\$)

 Un-notched
 187.4
 199.1
 14.3
 49.1

 notched
 -- 295.0
 -- -- 

Notched-Un-notched ratio - 1.49 - 1



PAGE 14 NUMBER 4577 DATE Feb. 1961

1100°F age + Armco pickle

Specimen # .2% Y.S.(K.S.I.) T.S.(K.S.I.) Elongation (% in 2") R. of A. (%)

Un-notched notched

148.5

150.7 212.8 16.0

62.4

Notched-Un-notched ratio - 1.41 - 1



PAGE 15 NUMBER 4577 DATE Feb. 1961

#### TABLE V

### C. - Compression ring-stress bar specimens

### 900°F age - Pickle solution + Salt spray for 6 days

Specimen #	Lbs. Deflection	Inches Deflection
1.	485	.190
2.	460	.200
3.	490	.200

## 1100°F age - Pickle solution - Salt spray for 6 days

Specimen #	Lbs. Deflection	Inches Deflection
1.	250	.190
2.	<b>2</b> 65	.200
3.	270	.190

### 900°F age + P.S. 61.32B cleaning + Salt spray for 6 days

Specimen #	Lbs. Deflection	Inches Deflection
1.	580	.200
2.	550	.200
3.	570	.200

# 1100°F age . P.S. 61.32B cleaning . Salt spray for 6 days

Specimen #	Lbs. Deflection	Inches Deflection
1.	445	.200
2.	435	.200
3.	440	.200

## 900°F age + Armco Pickle + Salt spray for 6 days

Specimen #	Lbs. Deflection	Inches Deflection
1.	65 65	.130
3.	60	.130 .130

## 1100°F age • Armco Pickle • Salt spray for 6 days

Specimen #	Lbs Deflection	Inches Deflection
1.	70	.140
2.	70	.130
3.	65	.130



PAGE 16 NUMBER 4577 DATE Feb. 1961

#### Discussion of Results:

17-4 PH was acid cleaned as specified in P.S. 61.32B and in two other acid solutions-Nitric-Ammonium Bifluoride-Water and Armco Pickling Method (Sulfuric-Water and Nitric-Hydrofluoric-Water solutions).

The test specimens- Compression Ring - Stress Ber, Notched and Un-notched tensiles - aged at 900°F and 1100°F before and after cleaning and pickling produced the following:

- 1. Compression test rings from 17-4 PH castings aged at 1100°F before and after immersion in the acid cleaning and pickling solutions revealed a greater ability to withstand deflection than the test rings aged at 900°F.
- 2. Compression test rings from 17-4 PH bar material aged at 900°F and 1100°F before and after acid immersion produced the same amount of deflection at different strength levels.
- 3. Tensile specimens from 17-4 PH bar material subjected to the same conditions as the compression test rings produced no significant evidence of deleterious effects of acid immersion.
- 4. The cleaning and pickling solutions did not embrittle 17-4 PH, but metallegraphic examination did show evidence of intergranular attack. Only the pickling solutions produced this evidence. Using 1100°F before acid pickling in the Nitric-Ammonium Bifluoride-Water and combination solutions of Sulfuric-Water and Nitric-Hydrofluoric Water produced the greatest amount of intergranular attack.
- 5. Whether the compression ring-stress bar specimens were immersed once or three times for maximum accumulation of time in the acid solutions made no significant difference maximum accumulation of time in the acid solutions produced only reduction of wall thickness of the ring specimens.

  Maximum accumulation of time in the acid solutions did not product failures of the compression ring stress bar specimens.

#### Recommendations:

Because of the difficulty in controlling aggregate immersion time, 17-4 PH steel parts should not be acid cleaned or pickled. Acid cleaning or pickling will not embrittle 17-4 PH, but susceptibility to failure due to integranular attack will increase with increase of immersion time in the pickling solutions.